

Tele® Wiring Diagram

Single Coil Bridge/HB Neck

3-way Switch

Position 1 - bridge
 Position 2 - neck and bridge parallel
 Position 3 - neck

